

1. BUILD A FRAME OF 2" X 4" WOOD AROUND INLET. DRIVE STAKES INTO GROUND AT LEAST 12 INCHES.

2. DIG AN 8 INCH DEEP TRENCH OUTSIDE FRAME.

3. ATTACH WIRE MESH TO FRAME EXTENDING MESH 2 INCHES INTO TRENCH.

4. ATTACH FILTER FABRIC TO FRAME EXTENDING FABRIC AT LEAST 8 INCHES INTO TRENCH. OVERLAP JOINT TO NEXT STAKE.

5. BACKFILL AND COMPACT SOIL IN TRENCH.




figure 19

DROP INLET  
FILTER FABRIC BARRIER

FRANKLIN  
ENGINEERING DEPT

DRAWN BY \_\_\_\_\_  
APPROVED BY \_\_\_\_\_  
NOT TO SCALE